



Fitting Instructions - Ford Escape 2013 Onwards (164)

Thank you for purchasing your cargo liner from our family-run business.

Please follow the steps below to install your liner:

INSTALL THE BASE & BACK OF SEATS FIRST ...

1. Remove luggage blind if required.
2. Lay the liner in approximate position the vehicle. Attach the 3 buckles on the liner around the rear seat headrest locator poles.

NOW THE SIDES ...

3. Attach the self-adhesive Velcro (supplied) to the relevant points on each side of the liner (location shown by arrows in below photo), remove the backing to the self-adhesive Velcro and, using the liner as a guide, attach directly to the cargo area sides.



REMOVEABLE BUMPER FLAP ...

4. Attach the separate bumper flap provided to the Velcro strip sewn along the tailgate end of the liner.

PLEASE NOTE: YOU MUST UNFASTEN THE BUCKLES AROUND THE HEADREST LOCATOR POLES BEFORE LOWERING THE REAR SEATS. NORTH AMERICAN CUSTOM COVERS WILL NOT BE ABLE TO REPLACE OR REFUND ANY DAMAGED LINERS WHERE THE ABOVE HAS OCCURRED.

Velcro Fixing Kit – 1 x 70 inch HOOK Velcro strip supplied, please cut to required lengths.